ZXL20-I FIT

INSTALLATION, MAINTENANCE & SERVICE

ACCENT & LANDSCAPE | ZX20 Series 31W (3100lm) | 120V - 277V | HK LED





Materials

6061-T6 Machined aluminum 304 stainless steel hardware

Fitting 1/2"-14 NPS male thread

Dimming

120V - Phase dimming 120V-277V - 0V-10V dimming


Installation and Adjustment



TURN OFF POWER BEFORE AND DURING WIRING TO POWER SUPPLY

Installation/Service must be done by a qualified electrician, and compliant with NEC and Local Codes.


- Secure the fixture fitting to the 1/2"-14 NPS female thread on mounting device (plate, box, spike, etc.).
- Connect 18 AWG solid input wires to the 120V, 230V or 277V power source using appropriate wire connectors.
- 3 Secure the mounting device with the fixture to mounting surface. For HK original mounting accessory, see the individual instruction for further detail of the installation.
- To adjust tilting position of fixture, loosen tilt adjustment screw with 3/16" hex key & 5/64" hex key, aim the fixture body and tighten the screw to secure the fixture in place. Do not tighten more than necessary.
- To adjust rotating position of the fixture, loosen rotation adjustment screw with 5/64" hex key, aim the fixture stem and tighten the screw to secure the fixture in place. Do not tighten more than necessary.



1




Lamp and Reflector Replacement








Optical Accessory Setting



For Optical Accessory Setting

0	Rotate hood counter-clockwise and
-	remove it from the body.



3 Pull out the snap ring from the hood.

